

Configuración de TVs Roku

1. Instalación física

Conexión HDMI:

Conecte un extremo del cable HDMI a su decodificador y el otro extremo a cualquier puerto HDMI disponible en la parte posterior o lateral de su televisor Roku.

Encendido:

Encienda tanto su televisor Roku como el decodificador.

Verificar conexión:

Con el control remoto de Roku, presione el botón Inicio, desplácese hasta Entradas y seleccione el puerto HDMI que utilizó (por ejemplo, HDMI 1) para asegurarse de que aparezca la imagen del decodificador.

2. Establecer como dispositivo predeterminado (Entrada de encendido)

De forma predeterminada, los televisores Roku se inician en la pantalla de inicio. Puede cambiar esto para que se inicie directamente en su decodificador cada vez que lo encienda:

Presione el **botón Inicio** en el control remoto de Roku.

Desplácese hacia abajo hasta **Configuración** y presione la flecha derecha.

Seleccione Sistema.

Seleccione Encendido.

Seleccione la entrada a la que está conectado nuestro e-RoomTV, normalmente el puerto HDMI 1 y pulse **Aceptar**.

Aparecerá una marca de verificación junto a su selección.

Apague y vuelva a encender el televisor para confirmar que ahora se ha configurado como dispositivo predeterminado.

3. Opcional:

Personalizar el nombre de la entrada

Para que sea más fácil identificarla en la pantalla de inicio, puede cambiarle el nombre:

Seleccione el icono de la entrada en la pantalla de inicio y pulse el botón de asterisco (*).

Seleccione Cambiar nombre de entrada y elija una etiqueta predefinida como "Decodificador de cable" o cree un nombre personalizado.

Discover connected CEC devices

To discover CEC devices:

1. Make sure that your CEC-compatible devices are connected to the TV with a suitable High Speed HDMI® Cable that supports HDMI® ARC and CEC control.
2. Turn on each device and make sure all devices are CEC enabled.

Tip: Some manufacturers have their own branded names for CEC functionality, so you might need to read the product documentation to correctly identify the CEC features of the device.

3. On the TV's Home screen menu, navigate to Settings > System > Control other devices (CEC) and then select Search for CEC devices. Press OK to repeat the discovery process, if necessary.

When finished, the TV displays a list of CEC devices that are connected to each HDMI® input, as well as any devices that had previously been connected. The TV remembers the names of multiple CEC devices even when they are no longer connected. If the list is longer than the allowed space, press * to see a complete list in a scrollable window.

Enable HDMI® ARC

HDMI® ARC is the audio return channel that is available on one of the TV's HDMI® ports. The audio return channel enables you to send a Dolby Audio™ signal back to a home theater receiver that is also sending an audio and video signal into the TV. Using HDMI® ARC reduces the number of cables needed and optionally lets you control the volume and mute state of the receiver by enabling system audio control.

HDMI® ARC is disabled by default. To enable HDMI® ARC, in the Home screen menu, navigate to Settings > System > Control other devices (CEC), and then highlight HDMI ARC. Press OK to enable or disable the feature.

Note: Enabling HDMI ARC also enables System audio control. After enabling HDMI ARC, you can disable System audio control if you prefer.